





Relay Rail



L	CCT	Flux	Power
1150	3000	855	7.7W
1150	3500	875	7.7W
1150	4000	900	7.7W
1150	7000	990	7.7W
2060	3000	1520	13.8W
2060	3500	1550	13.8W
2060	4000	1600	13.8W
2060	5000	1680	13.8W
2060	7000	1760	13.8W
2500	5000	2000	16.9W
2500	7000	2100	16.9W



Accessoars

Start cable	L
2500	26.5
5000	26.5

Accessoars

Link cable	L
48	8.3
300	26.5
500	26.5

Accessoars

Accessoars


Accessoars

Max 6m

Accessoars

ALT.

Accessoars



L

L



Det är lämpligt att denna information överlämnas till användaren av anläggningen.



It is appropriate that this information is passed on to the users of the installation.



Ljuskällan ska enbart bytas ut av tillverkaren eller hans utsedda person.

The light source shall only be replaced by the manufacturer or his designated person.